


STEP 1: TO MOUNT WALL BRACKETS




STEPS:

- Sx³ and Fx³: Brackets installed 48 inches apart on center; 78 inches from the top of the cross bar attachment to the floor.
- Sx²: Brackets installed 32 inches apart on center; 78 inches from the top of the cross bar attachment to the floor.

NOTE: Installation height of the VeloGrip rack system will vary based on individual preferences, bicycle body style and frame size. If studs are not available VeloGrip has provided EZ Twist & Lock white, nylon wall anchors and accompanying anchor screws for your convenience.

However, VeloGrip is not responsible for any damage if wall anchors fail. VeloGrip highly recommends mounting at a minimum one bracket into a stud and preferably each bracket to a stud for optimal holding strength.

STEP 2: TO MOUNT THE CROSS BAR




STEPS:

- Aligned the bracket and cross bar holes
- Insert 2 ½ inch bolt as shown above.
- Lock into place with locking nut.
 - Repeat previous steps on other end of cross bar & bracket.
- Tighten bolt until snug with key wrench.

STEP 3: TO MOUNT SCUFF PLATES

(Recommended to assist with storing bikes in pivot position)




STEPS:

- Install scuff plates based on the center of hooks utilizing 2 inch wood screws provided.
- One scuff plat will not be aligned with a hook. Allows rear wheels of bikes a place to rest/locks into place bikes being stored in the pivot position.

NOTE: Sx² will have one less scuff plate than shown above. Height of installed scuff plates will vary based on individual preferences, bicycle frames and bicycle types (standard 15 inches above the floor).

STEP 4: TO INSTALL GEAR HAMMOCK



STEPS:

- Utilize the Velcro tabs on the gear hammock to wrap around the top of the brackets.
- Tighten the Velcro tabs to the desired tautness creating the desired hammock shape.

DISCLAIMERS & REQUIREMENTS:

- LOFT3 and LOFT2 Storage Racks are designed to perfectly align to traditional stud spacing and come with woodscrews for mounting.
- LOFT Storage Racks require each bracket to be solidly mounted to a stud or in mortar/masonry due to minimal bracket size. Multiple drill holes have been provided to assist with locating slightly irregular wall stud spacing.
- Failure to mount brackets to studs or solid masonry could result in damage to walls and equipment.

VeloGrip by VersionTwo.0 LLC is not responsible for any of the following:

- Damages that may be cause from installation of a VeloGrip Bicycle Rack System.
- Damages to the building structure (walls, plumbing or electrical wiring).
- Damages to any objects or other materials placed on the bike rack.
- Or any personal injuries from installation or utilization of VeloGrip products.